

---

# Computer Practical / Laboratory 4

Topic: Localization - Particle Filter

On Monday 12:10-13:10, Week 48 of the calendar year,  
you will complete the following tasks:

## T 1 – Particle Filter

In this computer practical, you will implement in Python a complete particle filter. A code skeleton with the work flow of the particle filter is provided for you. A visualization of the state of the particle filter is also provided by the framework. The following folders are included in the lab4\_framework.zip archive:

**data** This folder contains files representing the world definition (i.e. landmarks) and sensor readings used by the filter.

**code** This folder contains the particle filter framework with stubs for you to complete.

You can run the particle filter in the terminal: `python monte_carlo_localization.py`. It will not work properly until you completed the blanks in the code.

### 1.a

Fill in the code blank in the `sample_odometry_motion_model` function by implementing the odometry motion model as presented in the lecture "Probabilistic Motion Models - 2", slide 13. Comment on the meaning of each line. The function samples new particle positions based on the old positions, the odometry measurements  $\delta_{\text{rot1}}$ ,  $\delta_{\text{trans}}$  and  $\delta_{\text{rot2}}$  and the motion noise. This is done by passing each particle of the old set through the motion model in turn. Use the `numpy.random.normal` function for the motion noise and the parameters:  $[\alpha_1, \alpha_2, \alpha_3, \alpha_4] = [0.1, 0.1, 0.05, 0.05]$ . The function returns the new set of parameters after motion update.

Please also answer the following question: What is the value of the pose of the first particle drawn from the motion model?

## 1.b

Fill in the `compute_importance_weights` function and comment on the meaning of each line. This function implements the measurement update step of a particle filter as presented in the lecture "Probabilistic Sensor Models - 2", slide 25, using a *range-only* sensor. It takes as input positions  $l_k$  and observations  $z_k$  of landmarks. Note that individual observations are independent given a particle position  $x_i$  (see "Probabilistic Sensor Models - 1", slide 39). The function returns a list of weights for the particle set. See slide 11 of the lecture "Localization - Particle Filter - 2" for the definition of weights  $w_i$ . Instead of calculating a probability, it is sufficient to calculate the likelihood  $p(z|x, l)$ . Use the `scipy.stats.norm.pdf` function to evaluate this probability density function. The standard deviation of the normal distribution is  $\sigma_r = 0.2$ .

Please also answer the following question: What is the value of the weight of the first particle drawn from the motion model?

## 1.c

Fill in the `resampling` function by implementing stochastic universal sampling as presented in the lecture "Localization - Particle Filter - 3", slide 8. Comment on the meaning of each line. The function takes as an input a set of particles and the corresponding weights, and returns a sampled set of particles. Use the `numpy.random.uniform` function to draw random number  $r$ .

Please also answer the following question: What is the value of the pose of the first resampled particle?

## 1.d

Use the `plot_filter_state` function to evaluate your completed particle filter implementation on the data provided in the folder `data`. What is the value of the robot pose estimate for the time stamps 0, 5, and 10?

## Implementation Tips

We used dictionaries to read in the sensor and landmark data. Dictionaries provide an easier way to access data structs based on single or multiple keys. The `read_sensor_data` and `read_world_data` functions in the `read_files.py` file read the data from the files and create a dictionary for each of them with time stamps as the primary keys.

For accessing the sensor data from the sensor readings dictionary, you can use

```
sensor_readings[timestamp, 'sensor']['id']
sensor_readings[timestamp, 'sensor']['range']
sensor_readings[timestamp, 'sensor']['bearing']
```

and for odometry you can access the dictionary as

```
sensor_readings[timestamp, 'odometry']['r1']
sensor_readings[timestamp, 'odometry']['t']
sensor_readings[timestamp, 'odometry']['r2']
```

For accessing the landmark positions from the landmarks dictionary, you can use

```
position_x = landmarks[id][0]  
position_y = landmarks[id][1]
```